





Wireless room temperature, humidity and CO2 sensor

Installation sheet

OMA0584



To the junction box



To the wall

