





# Temperature- and humidity sensor with external 1.8m measure element Installation sheet

**OMA0583**



To the junction box



To the wall

